HOW TO UPDATE CHANNELS AND EPG(TV GUIDE)

Perform these steps Daily to minimize buffering issues.

Update Channels: Arrow to the left Menu Bar and select
Refresh(C). Click Center Button(on remote) to CLOSE. Then
click Back Button when OK appears. Done.

Refresh ERG: Arrow over and select Settings(E). Arrow down

Refresh EPG: Arrow over and select Settings(). Arrow down and select EPG Teleguide. Click Center Button to select Reload EPG Teleguide. When completed, click the Back Button. Done.